Activation of the automatic cut-off function.
The receiver will switch off automatically after the chosen time

1 Switch on the power supply



Power on

2 Activating / deactivating of the automatic cut-off



5 s

Press at the same time until...

A



...the LEDs go on...
...and off...

The automatic cut-off is activated

B



...the LEDs go on...
...and off...



...and go on again...



...and off


The automatic cut-off is deactivated

Setting the operating time

1 Open the setting mode



Press simultaneous on both buttons



Press immediately and simultaneously again on the MY and DOWN buttons until...



...the LEDs go on and off

2 Choose the cut-off time

A) Cut-off time = 3 hours



Press briefly on the DOWN button



The LEDs go on and off

B) Cut-off time = 6 hours



Press briefly on the MY button



The LEDs go on and off

C) Cut-off time = 12 hours



Press briefly on the UP button



The LEDs go on and off

3 Confirm the settings



Press until...



...the LEDs go on and off