Keygo 4 RTS [1841064]
Instruction Guide

1. Press and hold the **PROG** button on the back of the existing Somfy RTS remote control until the motor jogs.

2. Press and hold the outer left and outer right buttons on the Keygo 4 RTS remote control simultaneously under the indicator light flashes.

3. Briefly press your preferred control button on the Keygo 4 RTS control. The motor will jog to confirm the pairing is successful.



